

MODEL: BiM22 - Front
size: 215mm x 175mm
July 21, 2009
Color: Black

Limited 90-Day Warranty

Tech2Go warrants this product to be free from defects in workmanship and materials, under normal use and conditions, for a period of 90 days from the date of original purchase.

Should this product fail to function in a satisfactory manner, it is best to first return it to the store where it was originally purchased. Should this fail to resolve the matter and service still be required by reason of any defect or malfunction during the warranty period, Tech2Go will repair or, at its discretion, replace this product without charge (except for a \$10.00 charge for handling, packing, return UPS/postage, and insurance). This decision is subject to verification of the defect or malfunction upon delivery of this product to the Factory Service Center listed below. The product must include proof of purchase, including date of purchase. Before returning this product for service, please first replace the batteries (if applicable) with fresh ones, as exhausted or defective batteries are the most common cause of problems encountered.

If service is still required:

1. Remove the batteries (if applicable) and pack the unit in a well padded, heavy corrugated box.
2. Enclose a photocopy of your sales receipt, credit card statement, or other proof of the date of purchase, if within the warranty period.
3. Enclose a check or money order payable to the order of Tech2Go, for the sum of \$10.00.
4. Send the unit prepaid and insured, to the Factory Service Center listed below.

Consumer Repair Department
Tech2Go Inc.
1330 Goodyear Drive
El Paso, TX 79936-6420

Disclaimer of Warranty

NOTE: This warranty is valid only if the product is used for the purpose for which it was designed. It does not cover (i) products which have been damaged by negligence or willful actions, misuse or accident, or which have been modified or repaired by unauthorized persons; (ii) cracked or broken cabinets, or units damaged by excessive heat; (iii) damage to digital media players, CD's or tape cassettes (if applicable); (iv) the cost of shipping this product to the Factory Service Center and its return to the owner. This warranty is valid only in the United States of America and does not extend to owners of the product other than to the original purchaser. In no event will Tech2Go or any of its affiliates, contractors, resellers, their officers, directors, shareholders, members or agents be liable to you or any third party for any consequential or incidental damages, any lost profits, actual, exemplary or punitive damages. (Some states do not allow limitations on implied warranties or exclusion of consequential damages, so these restrictions may not apply to you.) This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Your acknowledgement and agreement to fully and completely abide by the above mentioned disclaimer of warranty is contractually binding to you upon your transfer of currency (money order, cashier's check, or credit card) for purchase of your Tech2Go product.

Distributed by Tech 2 Go, Inc. 1299 Main Street,
Rahway, NJ 07065-5024
MANUFACTURED IN CHINA.
Tech 2 Go is a trademark of Tech 2 Go, LLC.

© 2009 SDI Technologies, Inc. All Rights Reserved.
iHome is a registered trademark of SDI Technologies Inc.

BARBIE and associated trademarks and trade dress are owned by,
and used under license from, Mattel, Inc. © 2009 Mattel, Inc.
All Rights Reserved.

Printed in China

BiM22-072109-A

Barbie iHome water-resistant stereo mp3 player



BiM22

questions? call toll free:
1-866-TECH-022 (1-866-832-4022) (USA only)

For models that require more than one battery

- Do not mix with used or other battery types/brands
- Replace all batteries at the same time
- Do not open batteries
- Do not dispose of in fire
- Do not heat above 75°C (167°F)
- Do not expose contents to water
- Do not charge or recharge
- Do not install backwards

FCC Information

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This Class B digital apparatus complies with Canadian ICES-003.
Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Important Message to Consumers

Thank you for purchasing one of the Barbie™ brand's many top-quality electronic products. We would appreciate it if you take a few moments to read through these instructions. This will help you explain the safe and proper way to use this toy, and to help give it the long-lasting life that Barbie™ branded products are designed for.

Keep these instructions for future reference as they contain important information




Battery Installation


NOTE: THIS UNIT DOES NOT CHARGE IPOD



Off/On Button



Connection For Any MP3 Player



2 Headphone Jacks

Using the BiM22

Thank you for purchasing the BiM22. Designed to work with your iPod/MP3 player or any audio device, this system provides high quality audio that invites your music to come out and play. Please read the instructions carefully before operating the unit and keep for future reference.

Installing/Replacing Batteries

1. Push to open the battery compartment door located on the bottom inside of the unit.
2. Insert 4 "AA" R6 (UM-3) batteries (not included), checking that the + and - ends of the batteries match the drawing inside the battery compartment. We recommend the use of alkaline batteries for longer life.
3. Close the battery compartment cover.

For Best Performance

- We recommend the use of alkaline batteries for longer life.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
- Batteries are to be inserted with correct polarity.
- Remove exhausted batteries from the unit.
- Do not attempt to recharge non-rechargeable batteries.
- Remove the rechargeable batteries from the unit before charging.
- The supply terminals are not to be short-circuited.
- Batteries should be removed if the item will not be used for an extended period of time, such as a month or longer, to prevent battery leakage or damage.
- Rechargeable batteries should only be charged under adult supervision.
- Only batteries of the same or equivalent type recommended are to be used.

Listening to an iPod/MP3 player or other audio device

1. Plug the attached audio patchcord located inside the unit into the headphone or Line-out Jack on your iPod or other audio device.
2. Turn on your iPod/MP3 player or other audio device, press play and set desired volume on the device.
3. Press the Power On button located on the front of the unit.
4. Remember to turn unit OFF when not in use to save batteries.
5. For private listening, connect up to two sets of headphones to the headphone jacks located on the top front of the unit. Doing so temporarily disables the main speakers.

NOTE: Connected iPhones create audio interference noise when a call is received. Turn on Airplane mode to disable phone while playing music.

Maintenance

- Place the unit away from sources of direct sunlight or excessive heat.
- Protect your furniture when placing your unit on a natural wood and lacquered finish.
- Clean your unit with a soft cloth moistened only with mild soap and water. Stronger cleaning agents, such as Benzine, thinner or similar materials can mar the surface.

MODEL: BiM22 - rear
size: 215mm x 175mm
July 21, 2009
Color: Black